

FITTING INSTRUCTIONS



FLOOR PREPARATION

1

ACCLIMATIZE 24 HOURS IN ADVANCE

2

ELECTRICAL FLOOR HEATING

3

ELECTRICAL FLOOR HEATING

4

5

ELECTRICAL FLOOR HEATING

A

ELECTRICAL FLOOR HEATING

A1

WATER UNDERFLOOR HEATING

B

WATER UNDERFLOOR HEATING

B1

FITTING INSTRUCTIONS

6

7

8

9

10

11

12

13

14

15

16

17

FINISHING

18

19

PLACE FLOORCOVERING WITHIN 48 HOURS

20

